

Bonsaidrive Midi implementation firmware 0.52

Midi Data	Standard, Description
F0 7F 7F 06 01 F7	MMC, Stop
F0 7F 7F 06 02 F7	MMC, Play
F0 7F 7F 06 03 F7	MMC, Deferred Play
F0 7F 7F 06 04 F7	MMC, Fast Forward
F0 7F 7F 06 05 F7	MMC, Rewind
F0 7F 7F 06 06 F7	MMC, Record Strobe
F0 7F 7F 06 07 F7	MMC, Record Exit
F0 7F 7F 06 08 F7	MMC, Record Pause
F0 7F 7F 06 09 F7	MMC, Pause
F0 7F 7F 06 0D F7	MMC, Reset
F0 7F 7F 06 45 03 <i>sh sm sl</i> F7	MMC, Variable Play
F0 7F 7F 06 46 03 <i>sh sm sl</i> F7	MMC, Search
F0 7F 7F 06 47 03 <i>sh sm sl</i> F7	MMC, Shuttle
F0 7F 7F 06 44 06 01 <i>hr mn sc fr ff</i> F7	MMC, Locate
F1 0nnndddd	MTC Quarter Frames
F0 7F 7F 01 01 <i>hr mn sc fr</i> F7	MTC Full Message
C0 nn	MIDI Program Change selects clip number nn+1
C1 nn	MIDI Program Change selects clip number nn+128
C2 00	MIDI Program Change increase clip number +1
C2 01	MIDI Program Change decrease clip number -1