

bonsaiDRIVE SDI-Option Assembly Instruction



The SDI option contains the following items:

- 1 pc. SDI PCB with back panel
- 2 pcs. M2.5 fixing screws
- 1 pc. fixing screw M3 x 4mm

and the assembly instruction you are reading right now.

1. Upload firmware 0.22 or higher which supports SDI options.

See bonsaidrive user manual for detailed instructions.
www.bonsaidrive.com/support.html

2. Disconnect the unit from mains!

3. Unscrew the 4 black Philips screws on the top and remove the caddy.

4. Plug in the PCB carefully!
Make sure the pins are plugged in the correct row and column.
Observe precautions for handling discharge sensitive devices.
Fix the PCB with the included M3 x 4mm screw.

5. Remove the black dummy plate on the back side of the unit.

6. Mount the SDI option back panel using the two M2.5 screws as shown in the picture.

7. Refit the caddy and start the unit.
Boot message HARDWARE INFO must show OPTION: SDI.

www.bonsaidrive.com
info@rosendahl-studiotechnik.com

